SR04 IR 868 MHz

Wireless room radiation temperature sensor



Datasheet

Subject to technical alteration Issue date: 28.07.2025 · A143





» APPLICATION

EasySens® radio surface mounted room sensor for measuring of radiation temperature in room and office applications.

This product is intended for use as part of an automation solution for (functional) buildings. It transmits sensor data within a building over short distances unencrypted by radio to suitable receivers. No personal data or location data is transmitted.

The product cannot communicate directly with the Internet and is not intended for applications that use the Internet to forward unprocessed sensor data. Automation stations that forward data via the Internet, e.g. to visualise the building status, must ensure that the data to be forwarded is encrypted as required by law.

» TYPES AVAILABLE

Radio room sensor radiation temperature

• SR04 IR

» SECURITY ADVICE - CAUTION

The installation and assembly of electrical equipment should only be performed by authorized personnel.



The product should only be used for the intended application. Unauthorised modifications are prohibited! The product must not be used in relation with any equipment that in case of a failure may threaten, directly or indirectly, human health or life or result in danger to human beings, animals or assets. Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Please comply with

- Local laws, health & safety regulations, technical standards and regulations
- Condition of the device at the time of installation, to ensure safe installation
- This data sheet and installation manual

Seite 2 / 5 Stand: 28.07.202

» GUIDELINES FOR DEVICES WITH SOLAR ENERGY STORAGE

Due to the energy-optimized EnOcean radio technology used in "EasySens[®] wireless sensors, the devices can work without batteries and self-charge themselves using electric energy generated by integrated solar cells. This makes the devices almost maintenance free and environmentally sound due to not having to replace batteries.

For optimum use, the device should be mounted in a location with sufficient ambient brightness. Minimum illumination of 200 lx (artificial light or ambient) is required for at least 3 to 4 hours each day. (The health and safety regulations at work require a minimum illumination of 500 lx for office workplaces).

The solar cell should be mounted facing towards the window direction if possible. If the device has a temperature sensor, then even periodic direct sun radiation should be avoided due to incorrect false temperature readings.

The mounting position should be selected so that the device will not be obstructed in the future: for example by placement areas, additional furniture or roll-fronted cupboards.

The sensor is supplied in an operational state. If the sensor has been stored in darkness for longer periods, the internal solar energy storage will most likely need to be recharged. This would normally happen automatically during commissioning or during initial start up in ambient light. If the initial charge is not sufficient, the sensor will reach its full operating state up to 3 to 4 days, if the requirements for minimum illumination per day are met. The sensor will then transmit continuously in darkness as specified f (2/3 days on factory default telegram timing). Depending on the application it is also possible for the devices to operate in darker rooms (with brightness <100 lx) by using the battery back-up option. Batteries to be used are listed in accessories.

The operating time when using batteries will depend on the transmission frequency as well as the component aging and the self-discharge of the battery. Standard operating time will be 5-10 years on factory default telegram timing. Changing of the device from solar to battery operation is done automatically by simply adding a battery to the device.

» REMARKS TO ROOM SENSORS

Location and Accuracy of Room Sensors

The room sensor should be mounted in a suitable location for measuring accurate room temperature. The accuracy of the temperature measurement also depends directly on the temperature dynamics of the wall. It is important, that the back plate is completely flush to the wall so that there is sufficient circulation of air through the vents in the cover, otherwise, deviations in temperature measurement will occur due to uncontrolled air circulation. The temperature sensor should not be covered by furniture or other objects. Mounting next to doors (due to draught) or windows (due to colder outside wall) should be avoided.

Surface and Flush Mounting

The measuring result is influenced by the thermal characteristics of the wall. A solid concrete wall responds to thermal fluctuations within a room in a much slower than a light-weight structure wall. Room temperature sensors installed in flush-mounted boxes have a longer response time to thermal variations. In extreme cases they detect the radiant heat of the wall even if the air temperature in the room is lower for example. The quicker the dynamics of the wall (temperature acceptance of the wall) or the longer the selected inquiry interval of the temperature sensor is the smaller the deviations limited in time are.

» INFORMATION ABOUT EASYSENS® (RADIO) / AIRCONFIG GENERAL USAGE





EasySens® - airConfig

Basic information about EasySens® radio and about general usage of our airConfig software, please download from our website. https://www.thermokon.de/direct/files/airconfig-software-manual.zip

» OVERVIEW OF THE RADIO TELEGRAMS





EEF

The structure of the data contained in the telegram can be found in the EEP (EnOcean equipment profile) list provided by the EnOcean Alliance.

» PRODUCT TESTING AND CERTIFICATION





Declaration of conformity

The declaration of conformity of the products are available on our website https://www.thermokon.de/direct/en-gb/categories/sr04ir

Stand: 28.07.2025 Seite 3 / 5


»TECHNICAL DATA

Measuring values	temperature		
Radio technology	EnOcean (IEC 14543-3-10), transmission power <10 mW EEP A5-02-05		
Frequency	868 MHz		
Power supply	solar cell, internal super cap, maintenance free optional: backup battery LS14250		
Measuring range temp	0+40 °C		
Accuracy temp	±0,4 K (typ. at 21 °C)		
Measuring interval	WakeUp time = 100 sec. (default)		
Transmission interval	every 100 sec. at change >0,3 K, otherwise every 1000 sec.		
Enclosure	PC, pure white		
Protection	IP30 according to EN 60529		
Ambient condition	0+40 °C, max. 85% rH non-condensing		
Weight	50 g		
Mounting	to be mounted flat onto the surface using adhesive foil or screws		
Delivery content	adhesive foil		
Notes	integrated battery backup possibility for usage in dark rooms		

» MOUNTING ADVICE

Installation is made by gluing the sensor base plate to the smooth wall surface by means of the adhesive tape included. If required, the base plate can also be fixed by means of raw plugs and screws. Finally, the sensor is put on the sensor base plate.

The sensor is supplied in an operational status. Probably, the internal solar energy storage must be recharged after a longer storage of the radio sensors in darkness. In principle, the recharging process is done automatically during the first operating hours in daylight. For this purpose, please refer to the remarks "solar energy storage".




Seite 4 / 5 Stand: 28.07.2025

» FUNCTION DESCRIPTION

The value of the measuring resistors changes in relation with the sensor environment. In fact, the sensor is equipped with two measuring resistors: one for measuring the radiant temperature and the other for the room temperature. The resistor output value is the average of the two measuring one.

» COMMISSIONING - SHIPPING MODE (VALID FROM PRODUCTION DATE 19140)



After delivery the room operating unit might be in default shipping mode, in this case press the learn button (<1 second) at the rear of the device [Signal telegramm will be send. SIG -> 0x0F // shipping mode deacticvated].

For further shipment, it is possible to set the room operating unit back in default shipping mode. In this case the learn button must be pressed for >3sec [Signal telegramm will be send, SIG -> 0x0E // shipping mode activated].


In order to assure a correct evaluation of the measured values by the receiver, it is necessary to have the devices learned in by the receiver. This is done automatically by means of a "learn button" at the sensor or manually by input of the 32bit sensor ID and a special "learning procedure" between sender and receiver. The respective details are described in the corresponding software documentation of the receiver.

The sensor is supplied in an operational status. Probably, the internal solar energy storage must be recharged after a longer storage of the radio sensors in darkness. Basically, the recharging process is done automatically during the first operating hours in daylight. For this purpose, please refer to the remarks "Guidelines for Devices with Solar Energy Storage".

» SETTING OF TRANSMISSION TIME

The required wake up and transmitting interval is determined with jumpers. Consider also the labeling on the PCB.

TW (T_wake up)		TI (T_interval)	
=1		=1	+ +
=10	T. i	=10	
=100	į.C	=100	



Factory default:

T_wake up: 100 sec. (Measuring interval)
T_interval: 10 x (Transmission interval)

T send = 100 sec. wake up * 10 interval = 1.000 sec. = approx. 16 min.


Remark: The transmission frequency has a direct influence on the operating energy available in the energy storage and on the discharge time of the energy storage during operation.

» CRC8 CHECKSUM (VALID FROM PRODUCTION DATE 19140)

By default, the radio transmitter uses the checksum CRC8 in its telegrams (according to factory setting from 05/2019). This has the advantage that faulty telegrams can be better verified and sorted out on critical radio ranges. Radio receivers older than the TCM3xx only support a simple checksum. In this case, the radio transmitter must be set to simple checksum. To do this, the teach-in button must be pressed 5x consecutively following. The simple checksum is compatible with all receivers. If the transmitter is to be reset to CRC8 checksum, then the learn button must be pressed 3x consecutively.

Stand: 28.07.2025 Seite 5 / 5

» DIMENSIONS (MM)



»ACCESSORIES (OPTIONAL)

Raw plugs and screws (2 pcs. each) Battery LS14250 (Lithium-Thionylchlorid) Adhesive foil for fixing the base plate Item No. 102209 Item No. 315098 Item No. 234726

» NOTES ON DISPOSAL



The crossed-out wheelie bin symbol indicates that the product or removable batteries must not be disposed of with household or commercial waste. Within the EU, you are legally obliged to dispose of the product separately and appropriately in accordance with the national laws of your country. Alternatively, please contact your supplier or Thermokon Sensortechnik GmbH. Further information can be found at: www.thermokon.com