LK+ VOC (LCD) (Temp_rH) RS485 BACnet

Duct sensor for air quality, optional temperature and humidity



Datasheet

Subject to technical alteration Issue date: 21.06.2023 • A122





The following illustrations show the version with LCD

» APPLICATION

Air quality sensor for measuring VOC air quality, temperature and humdity in outdoor areas with 20.10 V output. LCD models with RGB background light have a transparent cover.

» TYPES AVAILABLE

Duct sensor VOC + temp + rH (opt.), optional with display - active RS485 BACnet MS/TP

- LK+ VOC (LCD) RS485 BACnet
- LK+ VOC (LCD) Temp RS485 BACnet
- LK+ VOC (LCD) Temp_rH RS485 BACnet
- optionally with shorter sensor tube, Type 100
 - LK+ VOC (LCD) 100 RS485 BACnet
 - LK+ VOC (LCD) 100 Temp RS485 BACnet
 - LK+ VOC (LCD) 100 Temp rH RS485 BACnet

» SECURITY ADVICE - CAUTION

The installation and assembly of electrical equipment should only be performed by authorized personnel.

The product should only be used for the intended application. Unauthorised modifications are prohibited! The product must not be used in relation with any equipment that in case of a failure may threaten, directly or indirectly, human health or life or result in danger to human beings, animals or assets. Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Please comply with

- Local laws, health & safety regulations, technical standards and regulations
- Condition of the device at the time of installation, to ensure safe installation
- This data sheet and installation manual

» PRODUCT TESTING AND CERTIFICATION



Declaration of conformity The declaration of conformity of the products are available on our website <u>https://www.thermokon.de/</u>.

»NOTES ON DISPOSAL



As a component of a large-scale fixed installation, Thermokon products are intended to be used permanently as part of a building or a structure at a pre-defined and dedicated location, hence the Waste Electrical and Electronic Act (WEEE) is not applicable. However, most of the products may contain valuable materials that should be recycled and not disposed of as domestic waste. Please note the relevant regulations for local disposal.

» GENERAL REMARKS CONCERNING SENSORS

Especially with regard to passive sensors in 2-wire conductor versions, the wire resistance of the supply wire has to be considered. If necessary the wire resistance has to be compensated by the follow-up electronics. Due to self-heating, the wire current affects the measurement accuracy, so it should not exceed 1 mA.

When using lengthy connection wires (depending on the cross section used) the measuring result might be falsified due to a voltage drop at the common GND-wire (caused by the voltage current and the line resistance). In this case, 2 GND-wires must be wired to the sensor - one for supply voltage and one for the measuring current.

Sensing devices with a transducer should always be operated in the middle of the measuring range to avoid deviations at the measuring end points. The ambient temperature of the transducer electronics should be kept constant. The transducers must be operated at a constant supply voltage ($\pm 0, 2$ V). When switching the supply voltage on/off, onsite power surges must be avoided.

» BUILD-UP OF SELF-HEATING BY ELECTRICAL DISSIPATIVE POWER

Sensors with electronic components always have a dissipative power, which affects the temperature measurement of the ambient air. The dissipation in active temperature sensors shows a linear increase with rising operating voltage. This dissipative power has to be considered when measuring temperature. In case of a fixed operating voltage $(\pm 0, 2 \text{ V})$ this is normally done by adding or reducing a constant offset value.

Thermokon transducers can be operated with variable operating voltages. The transducers are set at the factory with a reference operating voltage of 24 V =.

At this voltage, the expected measuring error of the output signal will be the least. Other operating voltages, can cause a measurement deviation changing power loss of the sensor electronics.

A recalibration can be carried out directly on the unit or via a software variable (app or bus).

Remark: Occurring draught leads to a better carrying-off of dissipative power at the sensor. Thus temporally limited fluctuations might occur upon temperature measurement.

» APPLICATION NOTICE FOR HUMIDITY SENSORS

At regular environmental condition, it is recommended to calibrate the sensor annually to check the compliance with the accuracy required in the application. The following conditions can damage the sensor element or lead in long therm to loss of the specified accuracy:

Mechanical stress

Aggressive chemicals

• Contamination (e.g. dust / fingerprints)

A

Do not touch the sensor elements!

• Ambient conditions (e.g. condensation on measuring element)

Re-calibration or exchange of the sensor element are not subject of the general warranty.

» APPLICATION NOTICE FOR AIR QUALITY SENSORS VOC

Volatile organic compunds (VOC) are gaseous and vaporous substances of organic origin in the air. VOC-sensors monitor the significant part of humanly olfactory sensed air quality. (e.g. body odur | tobacco smoke | odur of materials, furniture, carpets, paint, adhesives, ...)

The VOC-Value is an application-specific indication for air quality and doesn't provide any information about individual components of VOC

A VOC sensor oxidises the organic molecules that collide with it, which results in changing the resistance of the semiconductor.

Any contact with the sensitive sensors must be avoided and will invalidate the warranty.

The VOC Sensor is factory calibrated and can be calibrated via USEapp subsequently, if needed.

» TECHNICAL DATA

Measuring values (type-dependent)	VOC, temperature and humidity			
Output voltage	2x 010 V or 05 V, min. load 10 k Ω (live-zero configuration via Thermokon USEapp)			
Network technology	RS485 BACnet MS/TP, Fail-safe Biasing required			
Power supply	1535 V = or 1929 V ~ SELV With alternating voltage, the correct polarity must be ensured			
Power consumption	max. 2,3 W (24 V =) max. 4,3 VA (24 V ~)	max. 2,3 W (24 V =) max. 4,3 VA (24 V ~)		
Measuring range temp. (type-dependent)	Temp Temp_rH 0+50 °C (default setting) , optionally configured via Thermokon USEapp			
Measuring range humidity (type-dependent)	Temp_rH 0.100% rH non-condensing, optionally (enthalpy, absolute humidity, dew point)			
Accuracy temperature (type-dependent)	Temp Temp_rH ±0,5 K (typ. at 21 °C)			
Accuracy humidity (type-dependent)	Temp_rH ±2% between 1090% rH (typ. at 21 °C)			
Air speed	min. 0,3 m/s, max. 12 m/s			
Calibration	self-calibration			
Sensor	VOC sensor (heated metal oxide semiconductor)			
Display (optional)	LCD LCD 29x35 mm with RGB backlight			
Enclosure (type-dependent)	enclosure USE-M, PC, pure white, with removable cable entry	LCD cover PC, transparent		
Protection	IP65 according to EN 60529			
Cable entry	M25, for wire max. Ø=7 mm, seal insert for fourfold cable entry			
Pipe (type-dependent)	VOC PA6, black, Ø=19,5 mm, length 150 mm Type 100 Length 70 mm	Temp Temp_rH PA6, black, Ø=19,5 mm, length 180 mm Type 100 Length 100 mm		
Connection electrical	Mainboard removable plug-in terminal, max. 2,5 mm²	Plug-in card removable plug-in terminal, max. 1,5 mm ²		
Ambient condition	0+50 °C, max. 85% rH short term condensation			
Notes	mixed gas sensors detect gases and vapours which can be oxidised (burnt): Body odours, tobacco smoke, exhalations emitted by materials (furniture, carpets, paint, glue)			

When several BUS devices are supplied by one 24 VAC voltage supply, it is to be ensured that all "positive" operating voltage input terminals (+) of the field devices are connected with each other and all "negative" operating voltage input terminals (-) (=reference potential) are connected together (in-phase connection of field devices). In case of reversed polarity at one field device, a supply voltage short-circuit would be caused by that device. The consequential short-circuit current flowing through this field my cause damage to it.

Therefore, pay attention to correct wiring.

» APPLICATION NOTICE



The Bluetooth dongle snaps into the socket easily. When removing, please fix the plug-in card (option PCB) so that it is not unintentionally pulled out.

» CONFIGURATION



The Thermokon bluetooth dongle with micro-USB (Item No.: 668262) is required for communication between USEapp and USE-M / USE L products. Commercial bluetooth dongles are not compatible.

Application-specific reconfiguration of the devices can be carried out using the Thermokon USEapp. The configuration is carried out in the voltage-supplied state.

The configuration-app and the app description can be found in the Google Play Store or in the Apple App Store.


*factory default settings

Object AV 20 - 0 (Unit Immerial)

»CONNECTION PLAN

To change the output voltage range (default: 0..10 V to 0..5 V) via jumper, the display must be removed from the board first.

LK+ VOC (Temp_rH) (LCD) RS485



» DIP SWITCH CONFIGURATION (PLUG-IN CARD)

The BACnet address of the device is set binary coded in the range of 1 ... 127 via 7 dip-switches. (the address 0 is reserved and cannot be selected).

Termination 120 Ω Not active*	B A Switch1	BACnet adress	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$
Baud ON 2 3 9600* 0N 2 3 19200	Switch2		
ON 0 2 3 38400 76800	• •	$\begin{bmatrix} ON & & & & \\ 0 & & & & \\ 0 & & & & \\ 0 & & & &$	Adress-Bsp.: 2+8+16+32+64=122



BACnet Objects, PICS and BIBBs:

USE-RS485 BACnet interface


A detailed description of the BACnet interface can be found at the following link: Download

Object	Access	Description	COV Increment	Unit
AI-1	R	Relative Humidity	0100 %	%rF
AI-6	R	VOC		%

		Object AV-38 = 1 (U	nit Si)	Object AV-38 = 2 (U	nit imperial)		
Object	t Access	Description	COV increment / L	COV increment / Unit		COV increment / Unit	
AI-0	D R	Temperature	0+250	°C	0+480	°F	
AI-2	2 R	Absolute humidity	080	g/m³	035	gr/ft³	
AI-3	3 R	Relative humidity	085	KJ/kg	040	BTU/lb	
AI-4	4 R	Dew point	080	°C	0200	°F	

 $O_{\text{bis}} = (A_{\text{b}} + A_{\text{b}} + A_{\text{b$

» DIMENSIONS (MM)



»ACCESSORIES (INCLUDED IN DELIVERY)

Mounting base

Mounting kit universal • Cover screw + screw cover• 2 Rawlplugs • 2 Screws (countersunk head) • 2 Screws (rounded head)

»ACCESSORIES (OPTIONAL)

Bluetooth dongle Filter stainless steel, wire mesh

RS485 Biasing Adapter

Item No. 631228 Item No. 698511

Item No. 668262 Item No. 231169

Item No. 811378